



# Size Matters

Camera Fitting List for

**JIMMY BO**



	CAMERA BRAND	MODEL	L	H	D	300	400	500	600	700
1	Canon	G7	106	72	43	x	x	x	x	x
2	Canon	G9	107	72	43	x	x	x	x	x
3	Canon	EOS 20D	145	107	71	x	x	x	x	x
4	Canon	EOS 30D	144	106	73	x	x	x	x	x
5	Canon	EOS 350D	126	94	64	x	x	x	x	x
6	Canon	EOS 40D	146	108	74	x	x	x	x	x
7	Canon	EOS 400D	127	94	65	x	x	x	x	x
8	Canon	EOS 450D	129	98	62	x	x	x	x	x
9	Canon	EOS 5D	152	113	74		x	x	x	x
10	Canon	EOS D60	150	107	75		x	x	x	x
11	Canon	Pro 1	118	91	72	x	x	x	x	x
12	Canon	S2 IS	113	78	76	x	x	x	x	x
13	Canon	S3 IS	114	78	76	x	x	x	x	x
14	Canon	S5 IS	117	80	78	x	x	x	x	x
15	Contax	Contax N Digital	152	117	69		x	x	x	x
16	Fujifilm	Finepix S1 Pro	148	125	80		x	x	x	x
17	Fujifilm	Finepix S5 Pro	147	113	74	x	x	x	x	x
18	Fujifilm	Finepix S20Pro	121	97	82	x	x	x	x	x
19	Fujifilm	Finepix IS Pro	147	113	74	x	x	x	x	x
20	Fujifilm	Finepix S5000	113	81	79	x	x	x	x	x
21	Fujifilm	Finepix S5200 zoom	114	112	85	x	x	x	x	x
22	Fujifilm	Finepix S5500	113	81	79	x	x	x	x	x
23	Fujifilm	Finepix S5600	113	112	85	x	x	x	x	x
24	Fujifilm	Finepix S5700	106	81	76	x	x	x	x	x
25	Fujifilm	Finepix S5800	106	81	76	x	x	x	x	x
26	Fujifilm	Finepix S8000 fd	112	79	78	x	x	x	x	x
27	Fujifilm	Finepix S9000z	128	93	129	x	x	x	x	x
28	Fujifilm	Finepix S9600	128	93	129	x	x	x	x	x
29	Konica	Dimage 7Hi	117	113	91	x	x	x	x	x
30	Konica	Dimage 7i	117	113	91	x	x	x	x	x
31	Konica	Dimage A1	117	114	85	x	x	x	x	x



# Size Matters

Camera Fitting List for

**JIMMY BO**



	CAMERA BRAND	MODEL	L	H	D	300	400	500	600	700
32	Konica	Minolta Dimage A2	117	114	85	x	x	x	x	x
33	Konica	Minolta Dimage A200	115	114	80	x	x	x	x	x
34	Konica	Minolta Dimage Z10	109	94	81	x	x	x	x	x
35	Konica	Minolta Dimage Z1	110	80	78	x	x	x	x	x
36	Konica	Minolta Dimage Z2	110	80	78	x	x	x	x	x
37	Konica	Minolta Dimage Z3	109	84	80	x	x	x	x	x
38	Konica	Minolta Dimage Z5	109	84	80	x	x	x	x	x
39	Konica	Minolta Dimage Z6	109	84	80	x	x	x	x	x
40	Konica	Minolta Dynax 5D	130	93	67	x	x	x	x	x
41	Konica	Minolta Dynax 7D	150	106	78		x	x	x	x
42	Leica	V-Lux1	141	85	142	x	x	x	x	x
43	Nikon	Coolpix 8700	113	105	78	x	x	x	x	x
44	Nikon	D40	126	94	64	x	x	x	x	x
45	Nikon	D70	140	111	78	x	x	x	x	x
46	Nikon	D80	132	103	77	x	x	x	x	x
47	Nikon	D200 Kit	147	113	74	x	x	x	x	x
48	Nikon	D300	147	114	74	x	x	x	x	x
49	Nikon	D40X	126	94	64	x	x	x	x	x
50	Nikon	D 50	133	102	76	x	x	x	x	x
51	Nikon	D 60	126	94	64	x	x	x	x	x
52	Nikon	F55	129	92	65	x	x	x	x	x
53	Nikon	F6	157	119	79				x	x
54	Nikon	F65	140	93	68	x	x	x	x	x
55	Nikon	F75	131	93	68	x	x	x	x	x
56	Nikon	F80	142	99	71	x	x	x	x	x
57	Nikon	FM3a	143	90	58	x	x	x	x	x
58	Olympus	C8080 widezoom	124	99	85	x	x	x	x	x
59	Olympus	E1	141	104	81	x	x	x	x	x
60	Olympus	E-3	142	116	74	x	x	x	x	x
61	Olympus	E-300	147	85	64	x	x	x	x	x
62	Olympus	E-330	140	87	72	x	x	x	x	x



# Size Matters

Camera Fitting List for

**JIMMY BO**



	CAMERA BRAND	MODEL	L	H	D	300	400	500	600	700
63	Olympus	E-350	100	65	35	x	x	x	x	x
64	Olympus	E-400	130	91	53	x	x	x	x	x
65	Olympus	E-410	129	91	53	x	x	x	x	x
66	Olympus	E-420	129	91	53	x	x	x	x	x
67	Olympus	E-500	129	95	66	x	x	x	x	x
68	Olympus	E-510	136	91	68	x	x	x	x	x
69	Olympus	E-520	136	91	68	x	x	x	x	x
70	Panasonic	DMC-FZ5	108	85	68	x	x	x	x	x
71	Panasonic	DMC-FZ7K	113	79	72	x	x	x	x	x
72	Panasonic	DMC-FZ7S	113	79	72	x	x	x	x	x
73	Panasonic	DMC-FZ8	113	79	72	x	x	x	x	x
74	Panasonic	DMC-FZ10	139	106	87	x	x	x	x	x
75	Panasonic	DMC-FZ18	118	88	75	x	x	x	x	x
76	Panasonic	DMC-FZ20	128	106	87	x	x	x	x	x
77	Panasonic	DMC-LC1	135	103	82	x	x	x	x	x
78	Panasonic	DMC-FZ30	141	86	138	x	x	x	x	x
79	Panasonic	DMC-FZ50	141	86	142	x	x	x	x	x
80	Panasonic	DMC-L1	146	87	77	x	x	x	x	x
81	Panasonic	DMC-L10	134	95	77	x	x	x	x	x
82	Pentax	ist D	129	95	60	x	x	x	x	x
83	Pentax	ist DL	125	93	67	x	x	x	x	x
84	Pentax	ist DS	125	93	66	x	x	x	x	x
85	Pentax	K10D	141	101	70	x	x	x	x	x
86	Pentax	K100D	130	92	70	x	x	x	x	x
87	Pentax	K110D	129	93	70	x	x	x	x	x
88	Pentax	K20D	142	101	70	x	x	x	x	x
89	Pentax	K200D	134	95	74	x	x	x	x	x
90	Samsung	GX-1S	125	93	67	x	x	x	x	x
91	Samsung	GX-10	141	101	70	x	x	x	x	x
92	Samsung	GX-1L	125	93	67	x	x	x	x	x
93	Samsung	GX-20	142	101	72	x	x	x	x	x



# Size Matters

Camera Fitting List for

**JIMMY BO**



	CAMERA BRAND	MODEL	L	H	D	300	400	500	600	700
94	Samsung	Pro 815	136	87	79	x	x	x	x	x
95	Sigma	SD 9	152	120	79		x	x	x	x
96	Sigma	SD 10	152	120	79		x	x	x	x
97	Sigma	SD 14	144	107	81	x	x	x	x	x
98	Sony	DSC-H1	108	92	81	x	x	x	x	x
99	Sony	DSC-H2	108	92	81	x	x	x	x	x
100	Sony	DSC-H3	106	69	48	x	x	x	x	x
101	Sony	DSC-H5	108	92	81	x	x	x	x	x
102	Sony	DSC-H7	110	83	86	x	x	x	x	x
103	Sony	DSC-H9	110	83	86	x	x	x	x	x
104	Sony	DSLR-A100 Kit	133	94	71	x	x	x	x	x
105	Sony	Alpha 200	131	98	71	x	x	x	x	x
106	Sony	Alpha 300	131	98	75	x	x	x	x	x
107	Sony	Alpha 350	131	98	75	x	x	x	x	x
108	Sony	Alpha 700	142	105	80	x	x	x	x	x
109	Sony	DSC-V3	120	72	63	x	x	x	x	x
110	Sony	S-DSLR-A700	142	105	80	x	x	x	x	x
111	Sony	DSC-R1	139	97	168	x	x	x	x	x
112	Sony	DSC-F828	134	91	156	x	x	x	x	x

## Note:

**For Jimmy Bo 200 please see the separate camcorder fitting list.**

Jimmy Bo 300, 400, 500, 600 and 700 are mainly designed for SLR cameras with small accessories and memory cards.

Size 300 mainly fits entry level SLR cameras with a short lens, size 400 accommodates semi professional SLRs with a mid size zoom lens and size 500 is designed for carrying semi professional cameras with either a long tele lens or a short lens with accessories/compact zoom lens.

Size 600 is mainly designed for carrying an entry level SLR (mid size zoom lens) with an additional small lens OR a flash.

Size 700 can hold semi professional camera (mid size zoom lens) with an additional small lens and a flash. There is some extra space on the front for small accessories on both 600 as well as 700.

Size 400, 500, 600 and 700 can hold all cameras which fits into size 300.